


Installation Instructions

Warning  The valve body must be rigidly anchored to a structural member within the island and dispenser to ensure breakage at the shear section in the event of a severe impact. In the event of a sever impact, failure to provide a rigid mounting to the island and dispenser may result in a break in the outlet pipe, resulting in a hazardous condition. The valve is designed to shear off when a bending movement is applied. When tightening the inlet pipe to the valve, care should be taken so that the force applied is torque and not a bending movement.

Caution  **Tighten threads to the following torque specifications:**

©2009 FFS F-6286 Rev. 2