


802 Pressure/Vacuum Vent Valves

Installation Instructions

Threaded Models


Apply pipe sealant tape to the male pipe threads prior to installing the valve body; do not use any type of liquid pipe thread sealing compound. Wrench the body to the riser pipe using the torque values listed below. Use EBW's 3/4" drive chain wrench (part #901-101-01) on the valve body and a 3/4" drive torque wrench with at least 100 ft. lbs. of torque range. Since the torque wrench is offset while using the chain wrench, off-set torque values are also listed below.

Model Size	Pipe Torque	Offset Wrench Reading
2" threaded model	45-70 ft. lbs.	35-60 ft. lbs.
3" threaded model	55-80 ft. lbs.	45-65 ft. lbs.



Slip-on Models with an O-Ring Seal

Remove all of the burrs and rust from the end of the pipe. Apply a film of oil or grease to the pipe and slide the valve body on. Tighten the lock screw to 24 - 36 in. lbs. of torque. If a suitable torque wrench is unavailable, thread the lock screw in hand tight and then turn it an additional 1/4 - 1/2 turn.



Maintenance

Periodically inspect the rain cap for any debris (i.e. signs of insect activity). Remove the cap, clean the screen and verify that the valve is clear of any debris.



Franklin Fueling Systems

3760 Marsh Road • Madison, WI 53718 U.S.A.

Tel: +1 608 838 8786 • Fax: +1 608 838 6433 • www.franklinfueling.com

Tel: USA & Canada 1 800 225 9787 • Tel: Mexico 001 800 738 7610

